

## **Questions & Answers**

Schwerman Trucking (Former)  
Commerce Number 53558-9447-14  
BRRts Number 03-13-000263

1. Do you want continuous sampling in all eight wells or just the four monitoring wells?

The bid states that "continuous soil samples shall be collected at two foot intervals and field screened".

The monitoring wells should have continuous sampling at the two foot intervals to approximately a depth of 15 feet. However, the piezometers should have continuous sampling starting at 15 feet below ground surface and use five foot intervals to a depth of approximately 40 feet.

2. Do you want soil sampling just to the watertable or to the bottom of the boring?

One soil sample shall be collected for each nested location from the interval of highest field screening results or closest to the water table smear zone and analyzed for PVOCs plus naphthalene and organic carbon.

3. Are we to sample well MW-16? The text doesn't list it to be sampled, but the table following the text does.

Do not sample well MW-16. It was either lost or destroyed.