

Insert pages for September 1, 2011 Wisconsin Commercial Building Code, Comm 61-66, into the International Building Code, 2009 edition

Safety and Buildings Division - Wisconsin Department of Safety and Professional Services

IBC Chapter 18, Insert 18J, Page 1 of 1

Insert between pages 410 and 411

Comm 62.1810 Deep foundations. (8) DESIGN CRACKING MOMENT. Substitute the following equation for IBC equation 18-11: $\phi M_n = 3(f'_c)^{0.5} (S_m)$.