
# Footing Size

# **Deck Layout**

Locate footings, beams, overhangs & dimension



## **Loading**

Live load = 40 PSF Dead load = 10 PSF Other = PSF Total load = PSF

Soil Bearing = \_\_\_\_\_PSF\*

\*soils greater than 2,000 PSF must be verified

PSF=pounds per square foot

### **Tributary Area**


(See Example on Right)

**Corner Footing** 

\_\_\_\_x\_\_\_=\_\_\_

Intermediate Footing

\_\_\_\_x\_\_=



#### **Tributary load**

Tributary area x total load= tributary load

Use this formula for tube forms, I.e. Sonotubes®


Tributary area x total load +  $(150 \left( \frac{\pi r^2 h}{1728} \right))$  = tributary load

Corner footing

$$x$$
  $(+150(\frac{\pi_{-2}^2}{1728})) =$ 

Intermediate footing

$$x$$
  $(+150(\frac{\pi^2}{1728})) =$ 



#### Footing Area

In<sup>2</sup> =inches squared

Tributary load ÷ Soil bearing=Load PSF × 144(change to square inches) = Area in In<sup>2</sup>

Corner footing

$$\div$$
 = × 144 = Area in In<sup>2</sup>

Intermediate footing

#### **Round footings** $\pi$ = 3.1416

**Square footings** 

 $2 \times \sqrt{area \div \pi}$  = diameter of footing (round to nearest inch)

Corner 

Intermediate  $2x\sqrt{\quad \div \pi} =$  inches

Corner 
$$\sqrt{\underline{\phantom{a}}} = \underline{\phantom{a}}$$
 inches Intermediate

 $\sqrt{area}$  = length of each side

(round to nearest inch)


# $\sqrt{\phantom{a}}$ = inches

### Footing thickness<sup>2</sup>

(Diameter or length - post width) ÷ 2= thickness (in inches)

\_\_-\_\_\_\_\_\_\_\_inches

Note: Footings may not be less than 8" thick



<sup>&</sup>lt;sup>2</sup>Footing thickness formula from American Wood Council. Prescriptive Residential Wood Deck Construction Guide, 2015.